


### WWW.SIRIUS-PCB.COM 13030046 THC15A WEEKLY PROGRAMMABLE TIMER



# ■Connection Diageram:



#### **■**Dimensions:



#### ■ DIN Rail Installation:

Advanced pre-setting one week before

Digital electronic time switch with daily programs

Repeat programs with 16 on/off setting: and manual over-ride

Lithium battry power reserve

Auto time error correction  $\pm$  60sec, weekly

### Technical Data:

Voltage rating: AC 220V 50/60Hz Voltage limit: AC 180V~250V

Hysteresis: ≤1 sec/day (25°C) ON/OFF operation:16 ON & 160FF Power consumption:2VA(max)

Display: LCD

Service life: Mechanial 10<sup>7</sup> Electrically 10<sup>5</sup>

Minimum interval:1 minute Weight: approx 120g

# Order voltage

230VAC

Count down:1 sec-99min 56sec Pulse:1 sec-59min 59sec

Load capacity: resistive load:16A/250V AC Lagging load:10A/250Vac

lamp load:2000W


Switching contact:1 changeover switch Power reserve:3 years (Lithium battery) Ambient temperature: -10~+40°C Ambient humidity: 35~85%RH

# DISPLAY:



1	P	TIMER
2	D+	DAT
3	H+	HOUR
4	M+	MIN
5	Ф	CLOCK
6	С	RESET
7	MANUAL	MANUAL C/R

### Meaning:



## Operating instruction:

- 1. To start switch: press reset Key, At the first time, if you want to the present time, please press "O" On Board, then press D+, H+, M+ to adjust the number to the present time.
- 2. Enter into programming as belows:

Step	Key	Programming
1	Press (P)	Setting1 ON time (display1on)
2	Press H+/M+	Setting hours and minutes
3	Press D+	To select same every day,or different time each day
4	Press (P)	Setting 1 off time (display 1 off)
5	Press H+/M+	Setting hours and minutes turn off time
6	Press D+	If you want the same every day, you need not press this key
7	Repeat step2-6	Set 2-16 on/off time
8	Press 🖰	End

If you do not require16 settings,press" ( "to the end.

## Note:

- 1. Time setting should according to the time sequence, couldn't be set crossly
- System with quit automatically if there's no operating within 10 seconds and no data is saved.
- 3. Function 3,4,5 can not be used simultaneously.