

**L1**  
lock indication

**L2**  
forward rotation indication

**L3**  
reverse rotation indication

**K1**  
view / shift

**K2**  
menu / exit

**K5**  
increasing

**K6**  
start / stop

**L4**  
power indication

**L5**  
Rs485 indication


**K4**  
reverse/forward rotation

**K3**  
save / lock

**K7**  
Diminishing

**VR**  
speed regulating potentiometer





# Installation dimension

